FAVI ENTERTAINMENT®
technology + design

© 2013 FAVI ENTERTAINMENT

IMPORTANT SAFETY NOTES

- Do not use speaker in areas where flammable gases or fumes are present.
- Do not expose speaker to water or other sources of moisture. Speaker contains an internal lithium ion battery.
- Do not expose speaker to extreme temperatures. Extreme temperatures will shorten the battery's life span.
- Use only the supplied micro USB charging cable to charge speaker. Using other USB chargers may overcharge the internal battery and shorten the battery's lifespan.
- Do not attempt to disassemble speaker or replace the internal battery. Doing so will void your warranty.

© 2013 FAVI ENTERTAINMENT

TECHNICAL SPECIFICATION

Output Power	1 x 3W
Input Power	DC 5V/500mA Micro USB
Battery Capacity	750mAh Li-ion
Play Time	6 hours
Dimensions	3.5 x 2.95 x 3.35 in
Weight	0.34 lbs

© 2013 FAVI ENTERTAINMENT

FAVI audio+

Wireless Speaker for iPhone

Quick Start Guide

FAVI ENTERTAINMENT®
technology + design

© 2013 FAVI ENTERTAINMENT

FEATURES





© 2013 FAVI ENTERTAINMENT

GETTING STARTED

1. Please fully charge speaker for 2 hours with micro USB cable via computer system or power adapter
2. Turn on speaker using ON/OFF Power Switch
3. Play iPhone music file or app
4. Place iPhone Speaker against Set to Connect™ Touch-point Set to Connect
5. Music should begin playing through audio+ Speaker

Volume Control

Volume can be adjusted directly from your iPhone

Power Status

- Blue Indicator Light (side) = Speaker is ON
- Red/Blue Rhythm Light is Flashing (front) = Speaker is Playing
- Red Indicator Light (side) = Speaker is Charging
- No Indicator Lights = Speaker is Off and Not Charging

© 2013 FAVI ENTERTAINMENT

WHAT'S IN THE BOX

1x Wireless Speaker
1x Micro USB Charging Cable
1x Quick Start Guide

PRODUCT REGISTRATION

Thank you for purchasing FAVI audio+!

To better serve you, please take a moment to register your product:

www.favientertainment.com/register

Product Registration allows us to send you important updates, service information and helpful hints. It will also make it easier should you ever need to call in for Technical Support. FAVI values your privacy and will never share your information with other companies.

© 2013 FAVI ENTERTAINMENT

TROUBLESHOOTING

Issue: *I can't connect my iPhone.*

Try: Make sure your iPhone's speaker is touching the Set to Connect™ Touchpoint logo. Please see photo on front of this manual for proper phone orientation.

Note: this model was specifically designed for iPhone (3 to current) and iPod Touch (3rd generation to current).

Try: Power switch is fully in the ON position. If you do not see a Blue indicator light please charge the speaker.

Try: Make sure iPhone is not connected to headphones, other external speaker or bluetooth audio device.

© 2013 FAVI ENTERTAINMENT